Distributor Mounted TFI-IV No Start	Pinpoint Test	А
--	---------------	---

- 2 A1: WERE TESTS IN EEC-IV QUICK TEST COMPLETED
- 2 A2: CHECK FOR GOOD BATTERY
- 2 A3: CHECK FOR SPARK AT COIL DURING CRANK
- 2 A4: CHECK FOR TFI POWER
- 2 A5: CHECK FOR PIP SIGNAL
- A6: CHECK FOR SPOUT SIGNAL
- 2 A7: CHECK VBAT AT COIL
- 2 A8: CHECK FOR COIL- SIGNAL
- 2 A9: CHECK FOR SPARK AT ALL WIRES
- 2 A10: CHECK PLUGS
- A11: CHECK FOR PIP FROM TFI
- 2 A12: CHECK FOR PIP SHORT HIGH IN HARNESS
- 2 A13: CHECK FOR PIP SHORT LOW IN HARNESS
- 2 A14: RESISTANCE CHECK OF TFI MODULE
- A15: CHECK FOR SPOUT IN HARNESS
- 2 A16: CHECK FOR SPOUT HIGH
- 2 A17: CHECK FOR SPOUT SHORT HIGH IN HARNESS

- <sup>2</sup> A18: CHECK FOR SPOUT SHORT LOW
- **2** A19: CHECK FOR SPOUT SHORT LOW IN HARNESS
- **2** A20: CHECK FOR PIP OPEN IN HARNESS
- 2 A21: CHECK IGN GND AT EEC PROCESSOR
- <sup>2</sup> A22: CHECK FOR IGN GND OPEN IN HARNESS
- <sup>2</sup> A23: CHECK FOR COIL- OPEN IN HARNESS
- 2 A24: CHECK FOR COIL- SHORT LOW IN HARNESS
- <sup>2</sup> A25: CHECK FOR COIL- SHORT HIGH IN HARNESS